


# GROUND TAXI CHART LRBC - FOR HELICOPTERS



LEGEND:

	GROUND TAXI GUIDANCE LINES
	HELICOPTER STAND
	HELICOPTER PARKING PLATFORM
	TOW GUIDANCE LINE

Note:

Ground taxi is allowed on TWY A, B, E and the RWY according to the chart. For parking on TWY E, helicopters will stop rolling across the designated helicopter stand, stop the engines and parking will be performed with marshaller assistance. Helicopters are not allowed to ground taxi in front of the FIXED WING STAND, they can only be towed in that area.

# GROUND TAXI CHART LRBC - FOR AIRPLANES

